

Technical Quick Guides

How to change installer and master codes

The installer code is used by the installer to configure all the settings on the Bosch 2/3/4000. By default, the installer code is 1234.

The master code is used by the primary user to add new users, add keyfobs, etc. By default, the master code is 2580.

Both of these codes should be changed from their defaults to avoid intruders altering the settings of the control panel.

Changing the installer code:

Using text keypad IUI-SOL-TEXT:

Enter the Installer code then # to enter the installer menu.

Press 2 (Access) then 1 (Installer Code).

Enter the desired installer code then press #.

When leaving the installer menu, make sure to press # to Confirm to Save Parameter Changes.

The installer code will now be changed.

Using icon keypad IUI-SOL-ICON:

Enter the Installer code then # to enter the installer menu. The STAY and AWAY icons will flash to indicate Installer mode.

The 4 digits of the installer code are held in locations 0181-0184. Enter 0181# to access the first digit of the code. This digit will show on the screen (eg if code is still 1234, the number 1 will be shown). Enter the desired first digit of the installer code then hit * (STAY). The new number will now show instead.

Hit # and you will be moved to location 0182 and should see the second digit of the installer code on the screen. Enter the desired second digit of the installer code then hit * (STAY). The new number will now show instead. Repeat for digits 3 and 4.



Once all 4 digits of the new installer code have been entered, the keypad will move to location 0185, the first digit of the master code. If you do not wish to change the master code, enter 960# to save changes and reset the system.

The new installer code will now be live.

Changing the master code:

Using text keypad IUI-SOL-TEXT:

Enter the master code, then 1, then # (eg 25801#). This takes you to the User Edit page.

Select User 1 (which is the master), then press 0 (*UserCode*).

Enter the desired master code then press #.

Leave the user edit menu. The master code has now been changed.

Using icon keypad IUI-SOL-ICON:

Enter the master code, then 1, then # (eg 25801#). The STAY and AWAY icons will flash to indicate editing settings.

Enter 1 then # (AWAY). This will allow us to edit the code for user 1, which is the master. A 1 will show on the screen.

Enter the desired master code then press #.

The master code has now been changed.

Note: the master code can also be changed on the icon keypad using the installer code by editing the data at locations 0185-0188, like changing the installer code.